

ESLON®-DC ESD

PVC CE401AS

ESD-Standard

CE401AS | clear

CHEMICALS

	Concentration %	A	B
Hydrofluoric acid	20	+	+
Hydrochloric acid	20	+	+
Sulfuric acid	50	+	+
Nitric acid	20	+	+
Phosphoric acid	85	+	+
Acetic acid	10	+	+
Caustic soda	30	+	+
Caustic potash	30	+	+
Hydrogen peroxide	30	+	+
Ammoniumfluoride	sat.	+	+
Pottasium chloride	sat.	+	+
Sodium chloride	sat.	+	+
Ammonia	100	+	+
Alcohols (Methyl, Ethyl)	100	+	+
Isopropyl alcohol ¹	100	+	+
Ketones (acetone, MEK)	100	-	-
Aromatics (benzene, toluene)	100	-	-
Esters (ethyl acetate, butyl acetate)	100	-	-
Halogens (Methylene chloride)	100	-	-
Formalin	100	+	+
Freon (TES)	30	+	+
Water	100	+	+
Washing-up liquid ²		+	+
Glass cleaner ³		+	+

DESCRIPTION
OF THE METHODS

Method A: Imersion condition:
72 hours (23°C room temperature)

Method B: Applying of 5ml liquid
and 12 hours of imersion

EVALUATION
OF THE METHODS

- + Not affected
- Surface whitening and/or swelling of the base material

REMARKS

- 1** Especially recommended cleaning solution
- 2** Composition of washing-up liquid: 15-30% anionic tensides, nonionic tensides: 5-15%, less than 5% amphoteric tensides
- 3** Composition of glass-cleaner: less than 5% anionic tensides, nonionic tensides, amphoteric tensides

www.eslon-dc.de

SEKISUI Chemical GmbH | Roßstraße 92 | 40476 Düsseldorf | Germany
Phone +49 (0) 211 / 36 977 0 | eslon@sekisui.de